

THE FOLLOWING NEEDS TO BE DONE ON ALL NEW SERVICES WITHIN THE PENDLETON COUNTY WATER DISTRICT SERVICE AREA IN ORDER TO HAVE THE WATER TURNED ON:

1. At least 30" cover on service line
2. At least 200 PSI AWWA approved pipe
3. Shut off valve installed somewhere on your line
4. Install a check valve on your line
5. Install a pressure regulator
6. If you install any type of hydrant on your service line, you must install a dual check valve in front of that hydrant.
7. Your cistern must be unhooked before your water can be turned on. (Cistern water and county water must be totally separate. Outside spickets on cisterns are allowable.)
8. You will need to provide us with a copy of your plumbing permit or farm exemption form.
9. A \$75 deposit is required for all new customers.

.....

**INFORMATION ON
PLUMBING INSPECTOR**

State Plumbing Inspector, Division of Plumbing

He is at Pendleton County Health Department on Hwy. 330 on Wednesday only between 8a.m and 9:30a.m. That phone number is (859) 298-8721.

A FARM EXEMPTION FORM CAN BE PICKED UP AND FILLED OUT FOR PEOPLE WHO OWN OVER 10 ACRES. THESE CUSTOMERS WILL NOT HAVE TO PURCHASE A PLUMBING PERMIT. FARM EXEMPTION FORMS ARE AVAILABLE AT THE WATER DISTRICT OFFICE OR THE PENDLETON COUNTY HEALTH DEPT.

IF THIS IS A NEW CONSTRUCTION DON'T FORGET TO CONTACT YOUR LOCAL ZONING OFFICE. THE PENDLETON COUNTY ZONING NUMBER IS 654-1108.